

Bosch/Radionics D2112

Zones/Points - 8 Hardwired

Battery -12 volt rechargeable Gel-Cell inside main panel

AC Transformer = 16.5 volts, screwed into outlet somewhere in house

Wireless -No

Downloadable - Yes

Panic Panic - Police (A key), Fire (B key) and Medical (C key)

Arm Away - Press 9 Key ALL & ON & Zone Lights turn ON (Arms all Zones)

Arm Stay -Press 0 Key PART & ON Lights turn ON (Arms all but Motions)

Instant Arm - Press 9 (ALL) or 0 (PART) key twice (No Delay Light turns ON)

Disarm- Enter User Code, If wrong code is entered press CLEAR and start again

Flashing OK- Alarm Memory, Arm then Disarm or press 3 + User Code to reset and clear

Alarm Memory- Press 4 then hold 6 key, last alarm should show, press CLEAR to exit

Reset Alarm - 3 + User Code

Reset Smoke -3 + User Code (If this does not work power down system and set for service)

Silence Trouble- Press CLEAR Key once

Bypass- 1. Arm system 9 (ALL) or 0 (PART), ON light and all Zone Lights will turn on

2. Press Zone to bypass (1 to 8), bypassed zone turns off and finish arming

Enable Chime- 1. Press 7 (WATCH TONE)(Keypad gives 1 beep)

2. Enter Owners Passcode (Keypad gives 1 beep)

3. Press 1 to 4 for Chime Option (see below) (Selected option 1 to 4 turns ON)

1 = Zone lights but no sound (Chime Disabled)

2 = Zone lights, keypad sounds short beep (This one works best)

3 = Zone lights, keypad sounds until CLEAR pressed (don't do this one)

4 = Zone lights, keypad sounds until Zone closed or CLEAR pressed

4. Press CLEAR to exit

Choose Zones 1. Press 8 (WATCH POINTS)(Keypad beeps) to Chime

2. Enter Owners Passcode (Master)(Keypad beeps)

3. Press Zones to chime (1 to 8) (Zone Light ON = Chime)

4. Press CLEAR to exit

Battery Test - 1 + User Code

(System will test battery for 4 minutes, if trouble keypad will sound tone)